

Rokka
play™


Instruction Booklet

The Rokka
Theatre Accessory Pack



Contents

Introduction	01
Product Information	02
Warnings - Installation & Usage	03
Warnings - Cleaning Care & Maintenance	04
Parts	05
Assembling the Rokka Theatre Accessory Pack	06



Introduction

Welcome to the Rokka Theatre Accessory Pack! We hope these grand curtains and colourful backdrop scene inspire your children to create many stories and performances, starring either themselves or their favourite characters. There is enough room for several children to sit back stage or in the wings, between curtain and backdrop.

Our youngest children like to join in with the older children with games of peek-a-boo through the curtains and the older ones show the younger ones the art of storytelling!

Please read the following information carefully before assembling your Rokka Theatre and keep this guide for future reference. If any components are missing or damaged please contact Rokka Play Ltd for a replacement before allowing your child to play on

the Rokka. This user guide is for the Rokka Theatre Accessory Pack, product number RP/ROK01/004.

Product Information

The fabric accessories are made from 100% cotton, using azo free dyes. The Rokka and its accessories have been independently tested and comply with EN 71 regulations (Safety of Toys). Rokka Play Ltd regularly checks the materials and workmanship it employs to produce its products.



Warnings – Installation & Usage

- Please ensure your child is supervised at all times whilst they are playing with the Rokka and the Theatre Accessory Pack.
- Do not allow children to stand or climb on the Rokka when on its side to prevent falling or tipping.
- To prevent injury to your child or damage to the Rokka Theatre Accessory Pack, do not allow children to swing on or pull on the spoons, either when attached to the Rokka or when being used freely.
- Ensure that the Rokka Theatre Accessory Pack is used on a level stable surface, to prevent tipping.
- Do not place the Rokka near an open fire or other sources of strong heat, such as electric bar fires, gas fires etc due to the risk of fire.
- Keep plastic bags and other packing materials that may pose a suffocation hazard away from children and safely discard as soon as possible.




Warnings – Cleaning, Care & Maintenance

- Do not use any replacement parts not manufactured by Rokka Play as this may affect your child's safety.
- Do not use the Rokka if any part or component appears to be broken, damaged or missing.
- To clean, we recommend that you either hand wash or sponge clean the curtains with a damp cloth in the first instance. Do not wash the screen printed image on the backdrop as this may cause damage to the image. Use a damp cloth for spot marks which may occur on the rest of the backdrop.
- As the fabrics are made from 100% cotton, repeated washing may cause the fabric to stretch slightly. Prolonged exposure in sunlight may cause fading of the fabric colours.
- Please also follow the guidance which came with the Rokka itself for care and maintenance.

DO NOT LEAVE THE ROKKA OUTSIDE IN THE RAIN OR IN DAMP CONDITIONS AS THIS MAY DAMAGE THE PROPERTIES OF THE MATERIALS.

Parts

Please check that you have all of the following components in the box



Rokka Theatre Accessory Pack parts:

A) Curtain


B) Beach scene backdrop

Assembling the Rokka Theatre Accessory Pack

The Theatre Pack can be assembled with your children, indeed it is intended that they should be able to attach the Curtain and Backdrop themselves. However, please ensure, that you have positioned the Rokka on its side for them first.


Step 1 Adding the spoons

With the Rokka on its side, insert all four big spoons from the original Rokka pack into the holes.



Step 2 Creating the stage

Insert the curtain pockets onto the spoons at the front of the Rokka (which have the widest gap between them). Then insert the backdrop onto the remaining two spoons.






And that's it!

Check out our website to see story ideas and Rokka Theatre performances in action.

www.rokkaplay.com



The Rokka, an adventure every day

New packs are constantly in development. Full details are provided on the website www.rokkaplay.com or you can ask your supplier for details.



Registered Address:

Bishop Fleming
Chy Nyverow
Newham Road
Truro
TR1 2DP
UK

www.rokkaplay.com
info@rokkaplay.com



©Rokka Play Ltd.

Rokka is a registered design,
No. 001708173-0001